

[Common, Brake fluid]

Brake fluid maintenance

<https://bekomcar.com/en/tutorial/pdf/4/>

⚠️ Avoid brake fluid contacting your car or your eyes.

Brake fluid is directly related to safety. This is a very important maintenance work. Also, improperly maintained brake fluid could lead to malfunctions of expensive ABS and other systems.



Below is a general case. Please check owner's manual for proper maintenance.

1. In general, you should change your brake fluid every two years.
2. Do a moisture test and replace it when it reaches 3%.
3. Measure moisture level and contamination level when replacing engine oil.

Tags

#전기차, #내연기관, #하이브리드, #LPG, #디젤, #휘발유, #CNG

Related contents & Comments

1. 8th Gen Civic 2.0 brake fluid bleeding
2. What are the DOT3, DOT4, DOT5.1 brake fluid differences?
3. 시빅 우핸들 브레이크오일 교환 (밀어내기식)
4. 브레이크오일 혼자 교환하기

브레이크오일은 가능한 엔진오일 교환시 간단하게 점검하는것도 좋겠다. .

Feb. 18, 2022, 3:18 p.m., #C364, (@sunjoo.moon)

SunJoo Moon , Edit Date: June 19, 2022, 3:36 p.m.

Disclaimer ! All cars are different, so please read the service manual for your vehicle before any repair work. bekomcar assumes no liability for property damage and/or injury incurred directly and/or indirectly as a result of any of the information contained in the website. Use this information at your own risk.